

Hayes command set

The **Hayes command set** (also known as the **AT command set**) is a specific [command language](#) originally developed by [Dennis Hayes](#)^{[1][2]} for the [Hayes Smartmodem 300 baud modem](#) in 1981.

The command set consists of a series of short text strings which can be combined to produce commands for operations such as dialing, hanging up, and changing the parameters of the connection. The vast majority of dial-up modems use the Hayes command set in numerous variations.

The command set covered only those operations supported by the earliest 300 bit/s modems. When new commands were required to control additional functionality in higher speed modems, a variety of one-off standards emerged from each of the major vendors. These continued to share the basic command structure and syntax, but added any number of new commands using some sort of prefix character – `&` for Hayes and [USR](#), and `\` for [Microcom](#), for instance. Many of these were re-standardized on the Hayes extensions after the introduction of the [SupraFAXModem 14400](#) and the market consolidation that followed.

The term "*Hayes compatible*" was^{[3][1]} and as of 2018 still is important within the industry.^[4]

History

Background

Prior to the introduction of the [Bulletin Board System](#) (BBS), modems typically operated on direct-dial [telephone lines](#) that always began and ended with a known modem at each end. The

modems operated in either "originate" or "answer" modes, manually switching between two sets of frequencies for data transfer. Generally, the user placing the call would switch their modem to "originate" and then dial the number by hand. When the remote modem answered, already set to "answer" mode, the telephone handset was switched off and communications continued until the caller manually disconnected.

When automation was required, it was commonly only needed on the answer side — for instance, a bank might need to take calls from a number of branch offices for end-of-day processing. To fill this role, some modems included the ability to pick up the phone automatically when it was in answer mode, and clearing the line when the other user manually disconnected. The need for automated outbound dialling was considerably less common, and was handled through a separate peripheral device, a "dialler". This was normally plugged into a separate [input/output](#) port on the computer (typically an [RS-232](#) port) and programmed separately from the modem itself.

This method of operation worked satisfactorily in the 1960s and early 1970s, when modems were generally used to connect dumb devices like [computer terminals](#) (dialling out) with smart [mainframe computers](#) (answering). However, the [microcomputer revolution](#) of the 1970s led to the introduction of low-cost modems and the idea of a semi-dedicated point-to-point link was no longer appropriate. There were potentially thousands of users who might want to dial any of the other thousands of users, and the only solution at the time was to make the user dial manually.

The [computer industry](#) needed a way to tell the modem what number to dial through software. The earlier separate dialers had this capability, but only at the cost of a separate port, which a microcomputer might not have available. Another solution would have been to use a separate set of "command pins" dedicated to sending and receiving commands, another could have used a signal pin indicating that the modem should interpret incoming data as a command. Both of these had hardware support in the RS-232 standard. However, many implementations of the RS-232 port on microcomputers were extremely basic, and some eliminated many of these pins as a cost saving measure.

Hayes' solution

Hayes Communications introduced a solution in its 1981 Smartmodem by using the existing data pins with no modification. Instead, the modem itself could be switched between one of two modes:

1. **data mode** in which the modem sends the data to the remote modem. (A modem in data mode treats everything it receives from the computer as data and sends it across the phone line).
2. **command mode** in which data is interpreted as commands to the **local** modem (commands the local modem should execute).

To switch from data mode to command mode, sessions sent an **escape sequence** string of three plus signs ("+++") followed by a pause of about a second. The pause at the end of the escape sequence was required to reduce the problem caused by **in-band signaling**: if any other data was received within one second of the three plus signs, it was not the escape sequence and would be sent as data. To switch back they sent the *online* command, "ATO". In actual use many of the commands automatically switched to the online mode after completion, and it is rare for a user to use the online command explicitly.

In order to avoid licensing Hayes's patent, some manufacturers implemented the escape sequence without the time guard interval (**Time Independent Escape Sequence** (TIES)). This had a major **denial of service** security implication in that it would lead to the modem hanging up the connection should the computer ever try to transmit the byte sequence "+++ATH0" in data mode. For any computer connected to the Internet through such a modem, this could be easily exploited by sending it a **ping of death** request containing the sequence "+++ATH0" in the payload. The computer operating system would automatically try to reply the sender with the same payload, immediately disconnecting itself from the Internet, as the modem would interpret the **ICMP** packet's data payload as a Hayes command.^[5] The same error would also trigger if, for example, the user of the computer ever tried to send an e-mail containing the aforementioned string.

Commands

The Hayes command set includes commands for various phone-line operations such as dialing and hanging-up. It also includes various controls to set up the modem, including a set of *register commands* which allowed the user to directly set the various memory locations in the original Hayes modem. The command set was copied largely verbatim, including the meaning of the registers, by almost all early 300 baud modem manufacturers, of which there were quite a few.

The expansion to 1200 and 2400 baud required the addition of a small set of new commands, some of them prefixed with an ampersand("&") to denote those dedicated to new functionality. Hayes itself was forced to quickly introduce a 2400 baud model shortly after their 1200, and the

command sets were identical as a time-saving method.^[6] Essentially by accident, this allowed users of existing 1200 baud modems to use the new Hayes 2400 models without changing their software. This re-inforced the use of the Hayes versions of these commands. Years later, the [Telecommunications Industry Association \(TIA\)/Electronic Industries Alliance \(EIA\)](#) raised the 2400-baud command set into a formal standard with the title **Data Transmission Systems and Equipment - Serial Asynchronous Automatic Dialing and Control, TIA/EIA-602**.

However, Hayes Communications were slow to release modems supporting higher speeds or compression, and three other companies led the way here – [Microcom](#), [U.S. Robotics](#) and [Telebit](#). Each of these three used its own additional command-sets instead of waiting for Hayes to lead the way. By the early-1990s, there were four major command sets in use, and a number of versions based on one of these. Things became simpler again during the widespread introduction of 14.4 and 28.8 kbit/s modems in the early 1990s. Slowly, a set of commands based heavily on the original Hayes extended set using "&" commands became popular, and then universal. Only one other command set has remained popular, the US Robotics set from their popular line of modems.

Description

The following text lists part of the Hayes command set, also called the **AT commands**: "AT" meaning 'attention'. Each command string is prefixed with "AT", and a number of discrete commands can be concatenated after the "AT".

The Hayes command set can subdivide into four groups:

1. basic command set – A capital character followed by a digit. For example, M1.
2. extended command set – An "&" (ampersand) and a capital character followed by a digit. This extends the basic command set. For example, &M1. Note that M1 is different from &M1.
3. proprietary command set – Usually starting either with a backslash ("\") or with a percent sign ("%"); these commands vary widely among modem manufacturers.
4. register commands – Sr=n where r is the number of the register to be changed, and n is the new value that is assigned. A [register](#) represents a specific physical location in memory. Modems have small amounts of memory on board. The fourth set of commands serves for entering values into a particular register (memory location). For example, S7=60 instructs the modem to "Set register #7 to the value 60". Registers usually control aspects of the

modem operation (e.g. transmission strength, modulation parameters) and are usually specific to a particular model.

Although the command-set syntax defines most commands by a letter-number combination (L0, L1 etc.), the use of a zero is optional. In this example, "L0" equates to a plain "L". Keep this in mind when reading the table below.

When in data mode, an [escape sequence](#) can return the modem to command mode. The normal escape sequence is three plus signs ("+++"), and to disambiguate it from possible real data, a guard timer is used: it must be preceded by a pause, not have any pauses between the plus signs, and be followed by a pause; by default, a "pause" is one second and "no pause" is anything less.

Syntactical definitions

The following syntactical definitions apply:^[7]

- `<CR>` Carriage return character, is the command line and result code terminator character, which value, in decimal ASCII between 0 and 255, is specified in register S3. The default value is 13.
- `<LF>` Linefeed character, is the character recognised as line feed character. Its value, in decimal ASCII between 0 and 255, is specified in register S4. The default value is 10. The line feed character is output after the carriage return character if verbose result codes are used (V1 option is used); otherwise, if numeric format result codes are used (V0 option is used), it will not appear in the result codes.
- `< . . . >` Name enclosed in angle brackets is a syntactical element. They do not appear in the command line.
- `[. . .]` Optional subparameter of a command or an optional part of AT information response is enclosed in square brackets. Brackets themselves do not appear in the command line. When the subparameter is not given in AT commands which have a Read command, the new value equals its previous value. In AT commands which do not store the values of any of their subparameters, and so have not a Read command, which are called action type commands, the action should be done on the basis of the recommended default setting of the subparameter.

Modem initialization

A string can contain many Hayes commands placed together, so as to optimally prepare the modem to dial out or answer, e.g. `AT&F&D2&C1S0=0X4`. Most modem software supported a user supplied **initialization string**, which was typically a long concatenated AT command which was sent to the modem upon launch.^[8] The V.250 specification requires all DCEs to accept a body (after "AT") of at least 40 characters of **concatenated** commands.^[9]

Example session

The following represents two computers, computer A and computer B, both with modems attached, and the user controlling the modems with **terminal-emulator** software. Terminal-emulator software typically allows the user to send Hayes commands directly to the modem, and to see the responses. In this example, the user of computer A makes the modem dial the phone number of modem B at phone number (212) 555-0100 (long distance). After every command and response, there is a **carriage return** sent to complete the command.

Modem A	Modem B	Comment
ATDT12125550100		User at modem A issues a dial command: AT-Get the modem's ATtention; D-Dial; T-Touch-Tone; 12125550100-Call this number
	<i>RING</i>	Modem A begins dialing. Modem B's phone-line rings, and the modem reports the fact.
	ATA	Computer at modem B issues answer command.
<i>CONNECT</i>	<i>CONNECT</i>	The modems connect, and both modems report "connect". (In practice, most modems report more information after the word CONNECT – specifying the speed of the connection.) Also, at this time, both modems will raise the DCD, or Data Carrier Detect signal, on the serial port.
abcdef	<i>abcdef</i>	When the modems are connected, any characters typed at either side will appear on the other side. The person at computer A starts typing. The characters pass through the modem and appear on computer B's screen. (User A may not see his own typed characters – depending on the terminal software's local echo setting).
	+++	The person at computer B issues the modem escape command. (Alternately, and more commonly, the computer B could drop the DTR, or Data Terminal Ready signal, to achieve a hangup, without needing to use +++ or ATH.)
	<i>OK</i>	The modem acknowledges it.
	ATH	The person at computer B issues a hang up command.
<i>NO CARRIER</i>	<i>OK</i>	Both modems report that the connection has ended. Modem B responds "OK" as the expected result of the command; modem A says NO CARRIER to report that the remote side interrupted the connection. The modems on both sides drop their DCD signals as well.

Compatibility

While the original Hayes command set represented a huge leap forward in modem-based communications, with time many problems set in, almost none of them due to Hayes *per se*:

- Due to the lack of a written standard, other modem manufacturers just copied the external visible commands and (roughly) the basic actions. This led to a wide variety of subtle differences in how modems changed from state to state, and how they handled error conditions, hangups, and timeouts.
- Each manufacturer tended to add new commands to handle emerging needs, often incompatible with other modems. For example, setting up hardware or software handshaking often required many different commands for different modems. This undermined the handy universality of the basic **Hayes command set**.
- Many **Hayes compatible** modems had serious quirks that made them effectively incompatible. For example, many modems required a pause of several seconds after receiving the "AT Z" reset command. Some modems required spaces between commands, while others did not. Some would unhelpfully change baud-rate of their own volition, which would leave the computer with no clue how to handle the incoming data.

As a result of all this, eventually many communications programs had to give up any sense of being able to talk to all "Hayes-compatible" modems, and instead the programs had to try to determine the modem type from its responses, or provide the user with some option whereby they could enter whatever special commands it took to coerce their particular modem into acting properly.

Autobaud

The Hayes command set facilitated [automatic baud rate detection](#) as "A" and "T" happen to have bit patterns that are very regular; "A" is "100 0001" and so has a 1 bit at the start and end and "T" is "101 0100" which has a pattern with (nearly) every other bit set.^[10] Since the RS-232 interface transmits [least significant bit](#) first, the according line pattern with *8-N-1* (eight data bits, no parity bit, one stop bit) is *01000001010001010101* (start and stop bits *italicized*) which is used as [syncword](#).

The basic Hayes command set

The following commands are understood by virtually all modems supporting an AT command set, whether old or new.

Command	Description	Comments
A0 or A	Answer incoming call	
A/	Repeat last command	Do not preface with AT , do not follow with carriage return. Enter usually aborts.
D	Dial	Dial the following number and then handshake P - Pulse Dial T - Touch Tone Dial W - Wait for the second dial tone R - Reverse to answer-mode after dialing @ - Wait for up to 30 seconds for one or more ringbacks , - Pause for the time specified in register S8 (usually 2 seconds) ; - Remain in command mode after dialing. ! - Flash switch-hook (Hang up for a half second, as in transferring a call.) L - Dial last number
E0 or E	No Echo	Will not echo commands to the computer
E1	Echo	Will echo commands to the computer (so one can see what one types if the computer software does not support echo)
H0 or H	Hook Status	On hook. Hangs up the phone, ending any call in progress.
H1	Hook status	Off hook. Picks up the phone line (typically you'll hear a dialtone)
I0 to I9	Inquiry, Information, or Interrogation	This command returns information about the model, such as its firmware or brand name. Each number (0 to 9, and sometimes 10 and above) returns one line of modem-specific information, or the word ERROR if the line is not defined. Today, Windows uses this for Plug-and-play detection of specific modem types.

L0 or Ln (n=1 to 3)	Speaker Loudness. Supported only by some modems with speakers. Modems lacking speakers, or with physical volume controls, or ones whose sound output is piped through the sound card will not support this command.	0 turns off speaker, 1 to 3 are for increasing volumes.
M0 or M	Speaker off, completely silent during dialing	M3 is also common, but different on many brands
M1		Speaker on until remote carrier detected (user will hear dialing and the modem handshake, but once a full connection is established the speaker is muted)
M2		Speaker always on (data sounds are heard after <code>CONNECT</code>)
O	Return Online	Returns the modem back to the normal connected state after being interrupted by the "+++" escape code.
Q0 or Q	Quiet Mode	Off - Displays result codes, user sees command responses (e.g. <code>OK</code>)
Q1	Quiet Mode	On - Result codes are suppressed, user does not see responses.
S <code>n</code>		Select register <i>n</i> as the current register
S <code>n</code> ?	Select current register Note that S <code>n</code> , ? and = <code>r</code> are actually three separate commands, and can be given in separate AT commands.	Select register <i>n</i> as the current register, and query its value. Using ? on its own will query whichever register was most recently selected.
S <code>n</code> = <code>r</code>		Select register <i>n</i> as the current register, and store <i>r</i> in it. Using = <code>r</code> on its own will store into whichever register was most recently selected.
V0 or V	Verbose	Numeric result codes
V1		English result codes (e.g. <code>CONNECT</code> , <code>BUSY</code> , <code>NO CARRIER</code> etc.)

X0 or X	Smartmodem	Hayes Smartmodem 300 compatible result codes
X1		Usually adds connection speed to basic result codes (e.g. <code>CONNECT 1200</code>)
X2		Usually adds dial tone detection (preventing blind dial, and sometimes preventing ATO)
X3		Usually adds busy signal detection.
X4		Usually adds both busy signal and dial tone detection
Z0 or Z	Reset	Reset modem to stored configuration, and usually also physically power-cycles the modem (during which it is unresponsive). <i>Z0</i> , Z1 etc. are for multiple stored profiles. &F is similar in that it returns to factory default settings on modems without NVRAM (non volatile memory), but it does not reset the modem

Note: a command string is terminated with a CR (`\r`) character

Although not part of the command set, a [tilde](#) character `~` is commonly used in modem command sequences. The `~` causes many applications to pause sending the command stream to the device (usually for half a second), e.g. after a *Reset*. The `~` is not sent to the modem.^[11]

Modem S register definitions

Register	Description	Range	Default value
S0	Number of rings before Auto-Answer	0–255 (0 = never)	0
S1	Ring Counter	0–255 rings	0
S2	Escape character	0–255, ASCII decimal	43 ("+")
S3	Carriage Return Character	0–127, ASCII decimal	13 (Carriage Return)
S4	Line Feed Character	0–127, ASCII decimal	10 (Line Feed)
S5	Backspace Character	0–32, ASCII decimal	8 (Backspace)
S6	Wait Time before Blind Dialing	2–255 seconds	2
S7	Wait for Carrier after Dial	1–255 seconds	50
S8	Pause Time for Comma (Dial Delay)	0–255 seconds	2
S9	Carrier Detect Response Time	1–255 tenths of a seconds	6 (0.6 second)
S10	Delay between Loss of Carrier and Hang-Up	1–255 tenths of a second	14 (1.4 seconds)
S11	DTMF Tone Duration	50–255 milliseconds	95 milliseconds
S12	Escape Code Guard Time	0–255 fiftieths of a second	50 (1 second)
S18	Test Timer	0–255 seconds	0 seconds
S25	Delay to DTR	0–255 (seconds if synchronous mode, hundredths of a second in all other modes)	5
S26	RTS to CTS Delay Interval	0–255 hundredths of a second	1 hundredth of a second
S30	Inactivity Disconnect	0–255 tens of seconds	0 (disable)

	Timer		
S37	Desired Telco Line Speed	0–10 Command options: <ul style="list-style-type: none"> • 0 Attempt auto mode connection • 1 Attempt to connect at 300 bit/s • 2 Attempt to connect at 300 bit/s • 3 Attempt to connect at 300 bit/s • 5 Attempt to connect at 1200 bit/s • 6 Attempt to connect at 2400 bit/s • 7 Attempt to connect in V.23 75/1200 mode. • 8 Attempt to connect at 9600 bit/s • 9 Attempt to connect at 12000 bit/s • 10 Attempt to connect at 14400 bit/s 	0
S38	Delay before Force Disconnect	0–255 seconds	20 seconds

V.250

The [ITU-T](#) established a standard in its [V-Series Recommendations](#), V.25 *ter*, in 1995 in an attempt to establish a standard for the command set again. It was renamed V.250 in 1998 with an annex that was not concerning the Hayes command set renamed as V.251. A V.250 compliant modem implements the A, D, E, H, I, L, M, N, O, P, Q, T, V, X, Z, &C, &D, and &F commands in the way specified by the standard. It must also implement S registers and must use registers S0, S3, S4, S5, S6, S7, S8, and S10 for the purposes given in the standard. It also must implement any command beginning with the plus sign, "+" followed by any letter A to Z, only in accordance with ITU recommendations. Modem manufacturers are free to implement other commands and S-registers as they see fit, and may add options to standard commands.

V.250 – Defined leading character sequences

Leading characters	Includes commands related to
+A	Call control (network Addressing) issues, common, PSTN, ISDN, ITU-T Rec. X.25, switched digital
+C	Digital Cellular extensions
+D	Data Compression, ITU-T Rec. V.42 bis
+E	Error Control, ITU-T Rec. V.42
+F	Facsimile, ITU-T Rec. T.30, etc.
+G	Generic issues such as identity and capabilities
+I	DTE-DCE Interface issues, ITU-T Rec. V.24, etc.
+M	Modulation, ITU-T Rec. V.32 bis, etc.
+P	PCM DCE commands, ITU-T Rec. V.92
+S	Switched or Simultaneous Data Types
+T	Test issues
+V	Voice extensions
+W	Wireless extensions

GSM

The ETSI GSM 07.07 (3GPP TS 27.007) specifies AT style commands for controlling a [GSM](#) phone or modem. The ETSI GSM 07.05 (3GPP TS 27.005) specifies AT style commands for managing the [Short Message Service](#) (SMS) feature of GSM.

Examples of GSM commands:[\[12\]](#)[\[13\]](#)

Command	Description
AT+CPIN=1234	Enter PIN code
AT+CPWD="SC","old","new"	Change PIN code from 'old' to 'new'
AT+CLCK="SC",0,"1234"	Remove PIN code
AT&V	Status
ATI	Status (Manufacturer, Model, Revision, IMEI , capabilities)
AT+COPS=?	List available networks 0-Unknown/2-Current/3-Forbidden, Longname, Shortname, Numerical-ID, "AcT"
AT+CSQ	Get signal strength. Answer: +CSQ: < rssi (more=better)>, < ber , less=better>
ATD*99#	Dial access point
AT+CGDCONT=1,"IP","access.point.name"	Defines PDP context ^[12]

GSM/3G modems typically support the ETSI GSM 07.07/3GPP TS 27.007 AT command set extensions, although how many commands are implemented varies.

Most USB modem vendors, such as Huawei, Sierra Wireless, Option, have also defined proprietary extensions for radio mode selection (GSM/3G preference) or similar. Some recent high speed modems provide a virtual Ethernet interface instead of using a [Point-to-Point Protocol](#) (PPP) for the data connection because of performance reasons (PPP connection is only used between the computer and the modem, not over network). The set-up requires vendor-specific AT command extensions. Sometimes the specifications for these extensions are openly available, other times the vendor requires an NDA for access to these.^[14]

Voice command set

Modems with voice or answering-machine capabilities support a superset of these commands to enable digital audio playback and recording.

See also

- [Access Point Name](#) (APN)

- [Command and Data modes \(modem\)](#)
- ITU-T Recommendations:
 - [H.324 \(video\)](#)
 - [T.31 \(fax\)](#)

Notes and references

1. Victoria Shannon (January 7, 1999). "The Rise and Fall of the Modem King" (<https://www.nytimes.com/1999/01/07/news/the-rise-and-fall-of-the-modem-king.html>) . *The New York Times*. "with a partner"
2. Georgi Dalakov. "The Modem of Dennis Hayes and Dale Heatherington" (<http://history-computer.com/ModernComputer/Basis/modem.html>) . Retrieved January 8, 2015.
3. "Hayes compatible". *Computerworld*. March 30, 1987. p. 61.
4. "How to Set Up a Hayes Compatible Modem" (<https://www.ibm.com/support/pages/how-set-hayes-compatible-modem>) . June 17, 2018.
5. Max, Schau (27 September 1998). "1+2=3, +++ATH0=Old school DoS" (<https://marc.info/?l=bugtraq&m=90695973308453&w=2>) . *Bugtraq mailing list*. Retrieved 8 December 2012.
6. Frank Durda IV, "The AT Command Set Reference - History" (<http://nemesis.lonestar.org/reference/telecom/modems/at/history.html>) Archived (<https://web.archive.org/web/20080415210519/http://nemesis.lonestar.org/reference/telecom/modems/at/history.html>) 2008-04-15 at the *Wayback Machine*, 1993
7. *AT Commands Reference Guide* (<http://jimgrayassoc.com/AT%20COMMANDS%20REFERENCE%20GUIDE.pdf>)
8. *Initialization Strings: Why, What & Where* (<http://home.intekom.com/option/faq48.htm>)
9. "5.2.1 Command line general format" (<http://www.itu.int/rec/T-REC-V.250/en>) (PDF), V.250 : Serial asynchronous automatic dialling and control (05/99, 07/03), ITU-T/Telecommunication Standardization Bureau
10. "Serial Interfaces" (<http://www.piclist.com/techref/io/serials.htm>) . PICList. Retrieved 2016-05-15.
11. "More Modem Commands" (<http://www.chebucto.ns.ca/Help/Dialup/MoreModemCommands.shtml>) . Chebucto Community Net. Retrieved 2016-09-12.
12. "Developers guidelines June 2010 AT commands for Sony Ericsson phones" (<https://web.archive.org/web/20110929223402/http://developer.sonyericsson.com/wportal/devworld/article/technology-more-atcommands?cc=gb&lc=en>) . Archived from the original (<http://developer.sonyericsson.com/wportal/devworld/article/technology-more-atcommands?cc=gb&lc=en>) on 2011-09-29. 090505
developer.sonyericsson.com

13. "*UC864-E Software User Guide*" (https://web.archive.org/web/20110714011104/http://www.m2m-platforms.com/data/1vv0300767_UC864-E_Software_User_Guide_Final_DRAFT.pdf) (PDF). Archived from the original (http://www.m2m-platforms.com/data/1vv0300767_UC864-E_Software_User_Guide_Final_DRAFT.pdf) (PDF) on 2011-07-14. 090505 m2m-platforms.com
14. "*Dan Williams' blog - That's when I reach for my revolver...*" (<http://blogs.gnome.org/dcbw/2009/03/20/that-s-when-i-reach-for-my-revolver/>) .

External links



The Wikibook *Serial Programming* has a page on the topic of: ***Serial Programming: Modems and AT Commands***

- List of AT commands: Basic (Hayes), Extended, Proprietary (<https://web.archive.org/web/2010815214002/http://www.activexperts.com/mobile-messaging-component/at/>)
- Hayes AT Command Reference Manual (https://web.archive.org/web/20151028101531/http://www.zoomtel.com/documentation/dial_up/100498D.pdf)
- A list of Hayes AT commands (<http://home.intekom.com/option/hayesat.htm>)
- 3gpp.org (http://www.3gpp.org/ftp/Specs/archive/27_series/27.007/27007-3d0.zip) , 3GPP AT command set for User Equipment
- Modem initialisation string (<http://home.intekom.com/option/faq48.htm>)
- Extended Hayes AT command parameters for SMS (https://web.archive.org/web/20080412121855/http://www.cellular.co.za/at_etsi.htm) (dead)
- Determining your Class of Fax / Modem (<https://web.archive.org/web/20081211123540/http://www.telemagic.com/support/kcenter/kbread.asp?results=YES&id=597&lv=0>)
- Openmoko: AT Commands (http://wiki.openmoko.org/wiki/Hardware:AT_Commands)
- Cell modem commands (http://www.sierrawireless.com/resources/faq/AirLink/Redwing/Redwing_GPRS_UsersGuide.pdf)
- ITU Standard V.250 (http://www.itu.int/rec/dologin_pub.asp?lang=e&id=T-REC-V.250-200307-!!!PDF-E&type=items)
- AT Commands Reference Guide (<https://web.archive.org/web/20120121072259/http://www.telit.com/module/infopool/download.php?id=542>) from Telit (dead)

Retrieved from

["https://en.wikipedia.org/w/index.php?title=Hayes_command_set&oldid=1084723621"](https://en.wikipedia.org/w/index.php?title=Hayes_command_set&oldid=1084723621)

Last edited 4 months ago by VulcanSphere

WIKIPEDIA
